

REMOTE CONTROL GOLF CART USER GUIDE





Congratulations of your purchase of this RC Vehicle! Please read all information in this manual thoroughly before use to ensure safe, convenient operation.

- Included in box:
- User Guide
 - RC Golf Cart
 - Remote Control Handset

INSTRUCTIONS


1. Battery Information

Ensure both golf cart and remote control unit settings are set to the "OFF" position. Using a screwdriver, unscrew the battery door compartment and insert batteries, following correct polarity and adhering to the battery warnings below. The golf cart requires 3 x AAA batteries and the remote control unit requires 1 x 9V battery (not included). Close the battery door and replace the screw on position.



2. Operation

Turn the golf cart and remote control settings to "ON" and use the remote control to steer the golf cart.



NOTES & TROUBLESHOOTING

- Remote control handset will function up to a distance of 30 feet (9 metres) from the golf cart.
- Fully charged batteries will allow the golf cart to function continuously for approximately 45 minutes.
- This product does not transmit well through obstacles such as buildings, metal structures and trees.
- Replace batteries if the vehicle does not operate as usual or signal range decreases noticeably.

SAFETY INFORMATION

Warning! Not suitable for children under 36 months. This product contains small parts which may be a choking hazard.



- Batteries are to be replaced by an adult.
- Non-rechargeable batteries are not to be recharged.
- Rechargeable batteries are to be removed from the toy before being charged.
- Rechargeable batteries are only to be charged under adult supervision.
- For best performance only the recommended batteries or their equivalent are to be used.
- Batteries must be inserted with correct polarity.
- Do not mix new and used batteries.
- Do not mix different types of batteries.
- The supply terminals are not to be short-circuited.
- This product is not recommended for use on loose dirt or wet surfaces.
- Do not immerse in water. Sponge clean only.
- This product is covered by the Waste Electrical and Electronic Equipment (WEEE) Regulations. It should not be discarded with normal household waste, but taken to your local collection centre for recycling. For further information please contact the local authority or approved disposal agency.



FCC WARNING

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Caution: Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications.

However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or experienced radio/TV technician for help.

Frequency : 27.145 MHz
FCC ID : YNIJAZWARES92171

BEFORE RETURNING ANY PRODUCT, CONTACT JAZWARES, INC. CUSTOMER SERVICE.
Customer service is available 9-6 EST at 1-800-370-1877.
Jazwares Inc.
1067 Shotgun Road
Sunrise, FL 33326
www.jazwares.com

MADE IN CHINA

© Jazwares, Inc. 2012

IMPORTANT:
Please save this instruction sheet.
It contains valuable product information.