

Congratulations on your purchase of the Wireless Mouse!
We hope you enjoy all the great features of the clock. To get the most out of your Wireless Mouse please read this manual as it provides tips and information about its various features.

SAFETY TIPS:

- Use this only as intended.
- To prevent fire or shock hazard, do not expose this unit to rain or moisture.
- Do not submerge the unit in any liquid
- Do not disassemble

Power Supply:

Warning:

Replacement of batteries must be done by an adult.
Do not mix old and new batteries.

Do not mix the alkaline, standard (carbon-zinc) and rechargeable (nickel-cadmium) batteries.

The supply terminals are not to be short-circuited.

Non-rechargeable batteries are not to be recharged.
Exhausted batteries are to be removed.

Only batteries of the equivalent type are to be used.

Batteries are to be inserted with the correct polarity.

Dispose of batteries properly.

Do not dispose of batteries in fire ; batteries may explode or leak.

Only use the adapter provided by the manufacturer.

The mouse takes 2 X AAA Batteries.


Technical Specifications:

- Nano receiver, plug-and-play
- Wireless carrier frequency: 2402MHz-2480MHz
- Perfect ergonomic design
- Zero delay 2.4GHz & 16 channel transmitted at the same time, to provide a linear 10 meters effective operating distance.
- Super 5 class intelligent power-saving mode, a battery can up to more than 6 months life
- GFSK / DSSS FM automatic function, anti-interference ability is improved more than 8 times
- 1000 dpi high precision, optical tracking engine
- USB charging function, energy saving and environmental protection

System Requirements:

- Available USB Port
- Windows® XP, Vista or Higher
- Macintosh OS 10.1 or Higher

Battery Information:




Installation Steps:

• Hold the mouse on both sides of the button, the battery cover can be opened automatically.

• Put into two AAA alkaline batteries (enclosed in the package)

• Insert the mini receiver into the computer spare USB interface, (suggested to insert on the front of the USB interface of computer, if need to use the back of computer USB interface, suggest to use the extended wire connection)



• Turn the On/Off Switch to On.

The mouse is all installed, please enjoy wireless fun!

Trouble Shooting:

* NOTE : After periods of inactivity, the mouse goes into sleep mode to conserve battery life. To wake the mouse simply move it in any direction and it should respond on the screen.

If the mouse is not working, please follow the next steps.

• Unplug receiver from computer terminal .
Put the receiver into the distance of the mouse within 30 cm.
While holding down the mouse left & right key and the wheel button 10 seconds.
At the same time, let go, quickly insert receiver into the computer terminal.

• Check the batteries, they may need to be replaced.

• If you are still having problems, restart your PC and allow it to load up then check the mouse.

PACKAGE CONTENTS

- 2.4 GHz Wireless Mouse with Nano Receiver
- 2 AAA Batteries
- Instruction Manual

2.4 GHz Wireless Mouse

USER GUIDE

Limited Ninety (90) Day Warranty:

WARRANTY COVERAGE

Jazwares, Inc.'s warranty obligation is limited to the terms set forth below.

WHO IS COVERED

Jazwares, Inc. warrants the product to the original purchaser or the person receiving the product as a gift against defects in material & workmanship as based on the date of the original purchase from an authorized dealer or retailer. The original sales receipt showing the product name & the purchase date from an authorized retailer is considered such proof.

WHO IS COVERED

Jazwares, Inc. warranty covers new products if a mechanical defect arises & a valid claim is received within the Ninety (90) Day Warranty Period. At its option, Jazwares, Inc. will either (1) repair the product at no charge, using new or refurbished replacement parts, or (2) exchange the product with a product that is new or which has been manufactured from new, or serviceable used parts & is at least functionally equivalent or most comparable to the original product in Jazwares, Inc.'s inventory.

Jazwares, Inc. warrants replacement products or parts provided under this warranty against defects in materials & workmanship from the date of the replacement or repair for ninety (90) days or for the remaining portion of the original product's warranty, whichever provides longer coverage for you. When a product or part is exchanged, any replacement item becomes your property and the replaced item becomes Jazwares, Inc. property.

**Replacement product can only be sent if all warranty requirements are met.
Failure to follow all requirements can result in delay.**

WHAT IS NOT COVERED - EXCLUSIONS & LIMITATIONS

The limited warranty applies only to the products manufactured by or for Jazwares, Inc. that can be identified by the trademark, trade name, or logo affixed to it. This limited warranty does not apply to any non Jazwares, Inc. hardware product or any software, even if packaged or sold with the product. Non Jazwares, Inc. manufacturers, suppliers, or publishers may provide a separate warranty for their own products packaged with the bundled product. Jazwares, Inc. is not liable for any damage to or loss of any programs, data or other information stored on any media contained within the product, or any non - Jazwares, Inc. product or part not covered by this warranty.

WHAT IS NOT COVERED - EXCLUSIONS & LIMITATIONS

This warranty does not apply

- (a) to damage caused by accident, abuse, misuse, misapplication, or non - Jazwares, Inc. product,
- (b) to damage caused by service performed by anyone other than Jazwares, Inc.
- (c) to a product or a part that has been modified without the written permission of Jazwares, Inc.

LIMITED WARRANTY DOES NOT COVER

- Shipping charges to return defective product to Jazwares, Inc.
- Product repair and/or part replacement because of improper installation, connections to improper voltage supply, abuse, neglect, accident, unauthorized repair or other cause not within the control of Jazwares, Inc.
- Damage or claims for products not being available for use, or for lost data or lost software.
- Damage occurring to product during shipping.
- A product that requires modification or adaptation to enable it to operate in any country other than the country for which it was designed, manufactured approved and/or authorized, or repair of products damaged by these modifications.
- Product lost in shipment and no signature verification receipt can be provided.
- Failure to operate per Owner's Manual.

BEFORE RETURNING ANY PRODUCT, CONTACT JAZWARES, INC. CUSTOMER SERVICE. Customer service is available 9-6 EST at 1-800-370-1877.

REPAIR OR REPLACEMENT AS PROVIDED UNDER THIS WARRANTY IS THE EXCLUSIVE REMEDY FOR THE CONSUMER. JAZWARES, INC. SHALL NOT BE LIABLE FOR ANY INCIDENTAL OR CONSEQUENTIAL DAMAGES FOR BREACH OF ANY EXPRESS OR IMPLIED WARRANTY ON THIS PRODUCT. EXCEPT TO THE EXTENT PROHIBITED BY APPLICABLE LAW, ANY IMPLIED WARRANTY OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE ON THIS PRODUCT IS LIMITED IN DURATION TO THE DURATION OF THIS WARRANTY.

Some states do not allow exclusions or limitation of incidental or consequential damages, or allow limitations on how long an implied warranty lasts, so the above limitations or exclusions may not apply to you

This warranty gives you specific legal rights. You may have other rights which vary from state to state. This warranty is only valid in the United States of America.

© Jazwares, Inc.

Need More Help?

Do Not Return Item to Store.

Call 1-800-370-1827 and speak to a customer service representative.

NOTES:



This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC rules.

These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications.

However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by switching the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

Reorient or relocate the receiving antenna.

- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC rules.

YNI JAZWARES 15295

YNI JAZWARES 13595

2.4 GHz Wireless Mouse

USER GUIDE

© Jazwares, Inc. 2011